atlantic uk
architectural hardware

Fitting Instructions – Atlantic DIN Bathlock/Atlantic DIN Radius Bathlock

ALKDINED60(finish)/ALKDINRED60(finish)

Date Modified: 19/02/2024

Last modified by: Brock Hutchins

For best results when fitting Atlantic UK DIN Dead lock follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

- DIN Euro Deadlock
- 3no. Machine Screws for holding face plate.
- Faceplate
- Keep
- 5no. Wood Screws
- Dust Box

1) Mark out the desired location of the DIN Lock on the door
2) Using the faceplate, mark out and drill/router out for the fore-end, making sure you account for both the faceplate and the fore-end that is attached to the lock body.
3) Drill out for the body, this is standard across all DIN locks and latches, ensuring that there is clearance for the dead lock to sit all the way in.
4) Once this fits properly, use 2no of the wood screws included and fasten the lock into the mortice you have drilled out.
5) Mark out and drill out for the Euro Profile hole is also a 60mm backset and 55mm below the centerline.
6) Using the 3no machine screws, attach the fore-end to the main body of the lock, and test the deadbolt tongue for function.
7) Using the Deadbolt tongue, mark out for the keep on the rebate of the door frame.

8) Using the keep, mark out where you will need to drill/router out for this, as well as the dust box.
9) Drill/router out for the keep and dust box, and then test for fit. Once fitting correctly, fix in place using 3no. of the wood screws provided.
10) Once you have fitted the Euro Cylinder and escutcheon, check for function and adjust as needed.