atlantic uk
architectural hardware

Fitting Instructions – DIN Lock Rebate Kits

ALKDINREB(finish)

Date Modified: 15/07/2024

Last modified by: Brock H

For best results when fixing a rebate kit follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:
X1 Rebate Block
X1 Strike Plate
X4 Screws

Follow fitting instructions for fitting a DIN Lock and then use the next steps.

1) Using the lock position on the door, offer up the rebate block and fasten it into place using the screws provided.
2) Next, using the lock (not included) transfer the tongue location to the other door.
3) Then, place the strike plate in the desired location and rebate out for the dust box (not included) and the strike plate.
4) Test fit the strike plate to ensure the fit is correct.
5) When satisfied with the fit, fasten into place using the remaining screws provided.