

## APPLICATION GUIDE FOR METAL-KOTE

- 1) ENSURE THAT THE SURFACE TEMPERATURE IS ABOVE 5 DEGREES.
- 2) ENSURE THE SURFACE IS THOROUGHLY CLEAN & DRY.
- 3) WIRE BRUSH TO REMOVE ANY FLACKING RUST.
- 4) ENSURE LAPS & FASTENERS ARE SECURE.
- 5) PRESSURE WASH TO REMOVE DEBRIS AND RUST RESIDUE.
- 6) ONCE DRY, APPLY METAL-KOTE AT A COVERAGE OF 25M<sup>2</sup> PER 20KG DRUM EITHER BY BRUSH OR, FOR LARGER AREAS SPRAY APPLICATION.