



Pic.1: Extend bars until the line, indicated with the pencil is level with the outer bar. Now tighten the silver nut making sure The point of the nut is in the centre of the line on the outer bar. Now you are ready to lay slates.



Pic 2: Rest the Jackson slate layer on battens as shown and put your first eave slate in place then nail. Continue this keeping the slates tight to each other.



Pic. 3: Rest the second eave slate on the Jackson Slate Layer and nail. Continue this leaving a gap of approx. 4mm to place the copper rivet into, continue this along that batten



Pic 4: First of the whole slates. Mark the front with a line approx. 25mm long, turn it face up and mark The back with approx. 100mm line.



Pic 5: Shows 100mm line.



Pic 6: Put your punch on the line as far as it can reach then make the hole.