

PLEASE READ MATERIAL SAFETY DATA SHEET AND COSHH DATA SHEET BEFORE USING
For full COSHH & Material Safety Data Sheets see your EcoProof specialist or visit www.EcoProof.co.uk

1. Uses:

EcoProof Strengthening Tape is a geotextile reinforcement tape used in conjunction with EcoProof Mastic Adhesive to prepare the surface ready for waterproofing with EcoProof Liquid Membrane or EcoProof Spray. It should be used to reinforce and cover joints, large gaps, pipe work, up-stands, 90° angles and any other detail and preparation areas.

2. Preparation:

- | | |
|-----|---|
| 2.1 | All surfaces should be dry and free from dust, grease and other debris. Any loose debris should be swept away; surfaces pressure washed and allowed to dry. |
| 2.2 | All surfaces should be structurally sound and stable before application. |
| 2.3 | Use EcoProof Mastic Adhesive to fill smaller gaps (above 3mm). For best results build up in thin layers and allowed to fully dry and cure. |
| 2.4 | Use EcoProof Strengthening Tape to cover joints, large gaps, pipe work, 90° angles and other detail. |

3. Application:

- | | |
|-----|--|
| 3.1 | Do not apply to wet or frozen surfaces, during or immediately prior to heavy rain. |
| 3.2 | Apply a generous layer of EcoProof to the preparation area (with a trowel or brush), cut a suitable length of EcoProof Strengthening Tape and place on the EcoProof layer (fury side facing down). Press down with a clean paint brush until smooth. Then apply another generous covering of EcoProof to cover the EcoProof Strengthening Tape and smooth over with brush. |
| 3.3 | Allow to fully cure before applying final EcoProof Liquid Membrane or EcoProof Spray membrane. |
| 3.4 | Apply at an ambient temperature (above 5°C) |
| 3.5 | Cures to touch in 1-4 hours (at 20°C) and is largely cured within 24 hours. |

4. Storage And Handling:

- | | |
|-----|---|
| 4.1 | Please follow appropriate health & safety measures when handling and applying EcoProof Strengthening Tape. Follow the specified safety measures while using in conjunction with other EcoProof products |
| 4.2 | Store above 5°C in a cool dry place with containers tightly fastened. |
| 4.3 | Do not allow uncured material to freeze. |
| 4.4 | |

- 4.5 Not subject to the controlled products or the transportation of dangerous goods regulations.
Keep out of reach of children.

5. Spillage & Clean Up:

- 5.1 **Large spills:** Pump into plastic containers and rework/dispose as per local legislation.
Small spills: Use non-combustible absorbent and shovel into a suitable container for disposal.
- 5.2 For general clean-ups, white spirits is recommended. For personal clean up of your hands/face, baby oil is recommended.

6. Limitations:

- 6.1 Drying and curing time will vary depending on temperature and humidity.
- 6.2 Wear eye protection and other suitable personal protective equipment (PPE).
- 6.3 For further information refer to the COSHH and MSDS data sheets.

EcoProof Strengthening Tape is manufactured for EcoProof LTD

The information provided is offered in good faith and is based on our current knowledge without guarantee of accuracy. We do not accept responsibility for damage and claims arising from handling, transport, storage or disposal of the product. The information on this data sheet applies only to the product named above.

This does not constitute a guarantee or warranty for any specific product feature and shall not establish a legally contractual relationship.

EcoProof Ltd, The Enterprise Zone, Portobello, Sheffield S1 4DP
Web: www.EcoProof.co.uk Email: info@EcoProof.co.uk
Tel: 01948 841018 Fax: 01948 841018