Honeywell Home

evohome

HR93 Radiator Controller

Quick Start Guide


FROM
resideo
www.resideo.com
Pittway Sarl, Z.A. La Pièce 6,
1180 Rolle, Switzerland

© 2025 Resideo Technologies, Inc. All rights reserved.
The Honeywell Home trademark is used under license from Honeywell International Inc.
This product is manufactured by Resideo Technologies, Inc. and its affiliates.

R32352867-001 A


1

EN Remove the existing TRV head
DE Alten Thermostatkopf entfernen
FR Enlever la tête thermostatique existante
NL Oude thermostaatknop verwijderen
IT Smontaggio della vecchia testina termostatica
ES Retirar el cabezal del termostato antiguo
DA Fjern det eksisterende følerelement



2

EN Separate the valve base
DE Ventilaufsatz montieren
FR Séparer l'embase de la tête
NL Kraanopzetstuk losnemen
IT Montaggio dell'attacco della valvola
ES Separar del termostato de radiador el módulo de acoplamiento de la válvula
DA Afmonter ventilsokkel



3


EN Select the adapter (optional)
DE Adapter wählen (optional)
FR Sélectionner l'adaptateur (facultatif)
NL Adapter selecteren (optioneel)
IT Scelta dell'adattatore (opzionale)
ES Selección del adaptador (opcional)
DA Vælg adapter (valgfri)

Resideo-Braukmann, Honeywell, MNG, Heimeier, Oventrop (02/1998), Siemens

M30 x 1.5




Danfoss RA




Comap/ Hertz


M28 x 1.5



Danfoss RAVL




Danfoss RAV



4


EN Mount the valve base
DE Ventilaufsatz montieren
FR Monter l'embase sur l'adapateur ou le corps
NL Kraanopzetstuk monteren
IT Montaggio del regolatore del radiatore
ES Montaje del termostato de radiador
DA Monter ventilsokkel






5

(EN) Inserting & changing batteries
(DE) Batterien einlegen & wechseln
(FR) Insérer ou changer les piles
(NL) Batterijen plaatsen/vervangen
(IT) Inserimento/sostituzione delle pile
(ES) Poner/cambiar pilas
(DA) Indsætning og udskiftning af batterier



6

(EN) Setting the position of the display
(DE) Position des Displays einstellen
(FR) Mettre le support d'écran
(NL) Stand van het display instellen
(IT) Regolazione della posizione del display
(ES) Ajuste de posición de la pantalla
(DA) Justering af display position



7

(EN) HR93 binding, see installer guide
(DE) HR93 verbinden, siehe Installationshandbuch
(FR) Liaison du HR93, voir le guide d'installation
(NL) HR93 verbinding, zie installatie instructie
(IT) Collegamento con HR93, vedi Guida di installazione
(ES) Vinculando HR93, ver la Guía de Instalación
(DA) HR93 binding (trådløs forbindelse), se installationsvejledning

(EN) Download full instruction guide on :
(DE) Download der Bedienungsanleitung unter:
(FR) Télécharger la notice détaillée sur :
(NL) Download volledige installatie instructie op:
(IT) Scarica le istruzioni complete da:
(ES) Descargar manual de instrucciones en:
(DA) Download komplet instruktionsvejledning på:



www.resideo.com