

Garden Furniture Care Sheet

Please retain this document for future reference

This product should provide years of enjoyment. It is made from natural raw material and it is therefore important that you understand the characteristics of timber.

Exposure to the Elements

During prolonged periods of dry weather, you may notice surface cracks appearing in the furniture. This is quite normal and is not detrimental to the strength of the furniture. These surface cracks will close up again in time.

During periods of prolonged wet weather or high humidity, the timber may swell resulting in components temporarily distorting. Again these will return to their original state when they dry out and will not effect the strength of the furniture.

Maintenance and Protection

Left untreated, your furniture will become grey in colour. If you wish to retain the original colour, you must treat the product with a suitable garden softwood preserver at least once a year. For best results, lightly sand the surface of your furniture with a fine grade sandpaper *in the direction of the grain* to remove any surface staining. Wipe off any dust and then apply the treatment following application guidelines from the manufacturer. We strongly advise keeping up an annual application of wood preserver to protect against rot and decay.

IMPORTANT: Ensure that the furniture does not become wet until the preserver is completely dry as the stain may leach onto your patio or garden.

If you are unable to store your furniture in a garage or shed during the winter months or periods of prolonged wet weather, it is strongly recommended that you cover the furniture with a suitable waterproof furniture cover.

Safety

These products have been tested to the appropriate British and European standards for strength and stability to ensure that they are fit for purpose. However, you should pay attention to the following:-

1. Read and follow assembly instructions closely.
2. Periodically check bolts and fittings for tightness as they may work loose over time, taking care not to over tighten fittings as this may split the timber. For this reason, we **do not** recommend the use of power tools to assemble your furniture.
3. Always place chairs and tables on a level surface.
4. When using parasols in conjunction with any tables, please ensure that a suitably weighted parasol base is used to stabilize the furniture.
5. Rocking and/or continually twisting the torso whilst seated, as well as displacing all your bodyweight to one side of the chair [or a combination of these actions], should be avoided since this may weaken the structural integrity of the chair.

Helpline

Should you experience any problems, need further advice or require replacement fixings then please contact the customer service help line or email support below.



Helpline: 01829 261121
Email: support@rowgar.co.uk
Web: www.rowgar.co.uk