


Slate Vent General Fitting

CODE **GRSV 45**
GRSV 45R



Fitting Instructions:

- 1) Cut the two slates directly below the slate vent as shown.
- 2) Cut an inverted "T" in the felt and fold back as shown. If a sarking board is to be used a hole should be cut in the board to match up with the slate vent.
- 3) Fix slate vent into position using holes provided.
- 4) Secure front of slate using a copper disc rivet.
- 5) Slates should then be dressed over the slate vent. A GRPA Flexible Pipe is available for connection to the GRSV45 slate vent spigot.

Slate Vent Airflow Characteristics:

Airflow m ³ /s	Differential airflow pressure (Pa)
0.037	28
0.060	64
0.083	122
0.109	190
0.130	310

PRODUCT CODE	TO ACHIEVE 5mm ² FREE AIR FLOW THE VENT NEEDS TO BE FITTED AT CENTRES	TO ACHIEVE 10mm ² FREE AIR FLOW THE VENT NEEDS TO BE FITTED AT CENTRES	TO ACHIEVE 25mm ² FREE AIR FLOW THE VENT NEEDS TO BE FITTED AT CENTRES
GRSV 45	2m	1m	400mm
GRSV 45	2m	1m	400mm

MANTHORPE BUILDING PRODUCTS LTD
MANTHORPE HOUSE
BRITAIN DRIVE
CODNOR GATE BUSINESS PARK
RIPLEY
DERBYSHIRE DE5 3ND

TEL: 01773 514 200
FAX: 01773 514 262
EMAIL: sales@manthorpe.co.uk
WEB: www.manthorpe.co.uk

DRN M.L.W.O

Date 01.08.03

The company maintains a policy of continuous development of its product range and reserves the right to amend the specification without notice.

DRG No

MBP 8084

Issue

A