


USER MANUAL

*Please read this manual before installing your product
and keep for future reference.*

Product name – 600 Basin

Product code – MURO-600WHBASIN



- **Single-person assembly**
- **We always recommend using professional tradespeople to install your product**

V1_2.3.2021

Important information

- Please read these instructions thoroughly and retain for future reference
- Please ensure the product is installed level on all 4 plains
- Tap flow rate should be reduced to suite the basin, allowing the tap to be turned on fully without over splashing of the basin
- Use cut out screw holes to fix the furniture to the wall
- Please inspect the product fully for any damage or defects prior to installation
- Ensure the correct waste is installed and is water-tight, periodically check the installation for leaks

Tools required

- Drill
- Screwdriver
- Spanner
- Water pump pliers
- Silicone
- Spirit level
- Protective cloth
- Slotted Basin Waste (not included)
- Tap (not included)

Installation

Please spend 5 minutes reading this section before commencing with the installation of your new furniture

1. Should any of your items have a defect, please do not install as returns will not be accept once fitted.
2. We advise that you use a qualified person to install your units, as any issues relating to poor fitting will not be accepted by the supplier.
3. You have purchased the handmade and in some cases hand painted product. Therefore, you may see some slight imperfections which the supplier may deem as acceptable.
4. This product is water resistant but NOT waterproof.
5. Please avoid direct sunlight as this will cause the painted surfaces to discolor.
6. Due to motion in transit, the cabinet doors and drawers may need to be adjusted after installation
7. Floor standing units must be fitted back to the wall through the back rail using suitable fixings. (not supplied)
8. When fixing to a stud or paneled wall, appropriate frame work should be installed to support the basins and units.
9. Where units or worktops have been cut out for services, all raw edges MUST be sealed against water ingress.

WALL HANGING INSTRUCTIONS

Wall Bracket




Snap or cut provided bracket in half. Fit to wall using suitable fixings (not provided)

Wall Hanging Hook

Insert hanging bracket into the pre-drilled holes at the back of the cabinet



Lock hanging bracket into the cabinet by flipping down the locking lever shown below




unlocked to insert into
cabinet holes

locked into cabinet

Hook Adjustment





Adjust from inside the cabinet



Raises and lowers the hook



Door/Drawer Adjustment





Provided with a cover to conceal adjustment screws



Silicone on top edge of the side panels only and lower basin on top of silicone to form a watertight seal

Note:

When tightening any connections, always place a cloth around the nut to prevent marks from the spanner.

Troubleshooting

Door not straight / not closing

See drawer adjustment guide above

Leaking

Check sealant, reapply if necessary

Maintenance

Please note that although these units have been designed to give years of pleasure and satisfaction, you will help maintain the original beauty of your bathroom by following these guidelines.

Melamine, vinyl and foil wrapped doors

Occasional marks, can in most cases, be removed with a soft damp cloth. More persistent marks can be removed using a non-silicone-based furniture cleaner. Hot soapy water should be avoided. Once the mark is removed, the area should be wiped over with a damp cloth to remove any excess and dried with a soft clean cloth. On no account should solvent or an abrasive cleaner be used as permanent damage to the finish could take place.

High Gloss Doors

Use a cleaning product not containing aggressive substances like acetone, alcohol, bleach etc. as those components could seriously damage the surface of the door. The best would be to use a soft cotton or micro fiber cloth with only water and a soft soap (containing a maximum 1% of liquid soap)

Carcass components

Do not use polish on any surfaces. A damp cloth with soapy water will clean off most marks or spills. On no account should any spillage, even water, be allowed to lie on the surface. Bleaches scouring pads and multi-surface cleaners should not be used.

Drawers, runners, door hinges.

These should be wiped out with a damp soapy cloth and wiped dry with a soft cloth as necessary. The roller runners and hinges are lubricated and should not be cleaned with a degreasing agent as this will affect the action of the moving parts. Never lean on partially or fully opened doors and drawers in order to gain access to the units. The hinges are specified to adequately support the weight of the door, plus small additional weights such as wire accessories. It is advised that once the bathroom has been installed, you should check every six months that all screws on the hinges are tight.

Worktops

Although the worktop is hard wearing, sharp objects will scratch and excessive heat will scorch the surface. Care should be taken not to drop any heavy objects onto the worktop as the surface may crack. For cleaning, a damp soapy cloth will clean off most spills. Bleaches, scouring pads and multi-surface cleaners should not be used. Corrosive liquids and make-up should be wiped off immediately. On no account should any spillage, even water, be allowed to lie on the surface.

Temperature, humidity, ventilation and proximity

Avoid excessive change in temperature and humidity. We would advise an extractor fan to be installed in all bathrooms which include furniture to reduce the chance of water ingress damage. The extractor fan should be used every time that the shower/bath is used and should be left switched on for a sufficient time afterward to allow for adequate ventilation. Ensure that the fan has been correctly sized for the room in use. The units, under no circumstance, should be fitted in a location where they are regularly subjected to contact with water.

Regulations

If it is your intention to remove and replace your bathroom fittings with 'like for like' units, then this is classed as 'non regulated' and no building regulations would be required. However, building regulation approval may be required if the bathroom refurbishment involves altering the drainage or the internal layout within the dwelling to accommodate the new fitting such as a second bathroom. In this instance, we would advise you contact the building control department at your local authority to discuss the need for a formal building regulation application

Macerator – current building regulations specify that a Sani pump smallbore system can be fitted in a dwelling where there is also a normal gravity discharge W.C. it should not be the only W.C. facility.

Electrical – remember that double pole isolating switches are required for all electrical points apart from special razor sockets. All work must conform to BS7671:2008 the current I.E.E regulations

Cleaning

To maintain the surface of your product, wipe with a clean damp cloth and wipe dry, do not use any abrasive cleaning agents or materials. If any harsh chemicals come into contact with the surface of the product, rinse and wipe clean immediately.