

Product features & benefits

- Single piece product is quick and easy to install
- Requires no special tools to install
- All weather fixing
- Ideal for use with PVC-U bargeboards, fascias and soffits
- UV stabilised for long-term protection
- Prevents entry of birds and large insects
- Weatherproof
- Maintenance free
- Gives extra security at verge against wind damage
- Can be used on existing roofs ('T' Strip only)
- Mortar-free, eliminating wet trades and associated problems
- Unaffected by settlement or differential movement
- Neat attractive finish
- T-strip connectors allow for a sprocket eaves and change in pitch up to 15°

Area of application

Suitable for:

- Refurbishment or new build
- Pitches 12.5°- 90°
- Slates and tiles

T Strip

Suitable for use with most plain and profiled concrete interlocking tiles.

For Bold Roll and Double Pantile fit the T-strip on top of the batten.

T-strip connectors allow for a sprocket eave and change in pitch up to 15°.

S Strip

Suitable for all fibre cement, natural and synthetic slates. Up to 8mm in thickness

Scot Strip

Suitable for use with products shown on S strip, on boarded roofs with top of batten fixing

Material

UV stabilized UPVC

Colours

T Strip


Black
Brown
White

S Strip



Black

Scot Strip

Black




The Uni-line Continuous Dry Verge provides a watertight and secure mortar free verge system suitable for concrete, clay interlocking and plain tiles. The S Strip and Scot Strip are suitable for use with natural or fibre cement slates.



Installation

1. The top of the gable wall should be reasonably level and free from obstructions. The roofing felt should be carried across the cavity and the battens fixed in the usual way, ensuring that they finish flush with the other wall or outer edge of the bargeboard.
2. Select a verge strip of the same or slightly greater length and cut to fit.
3. Make sure that the verge strip is taken to within 25mm (1") of the apex at the ridge. At the eaves, a piece should be removed from the horizontal flange in order to carry the line of the sprocket. (see illustration A)
4. The horizontal flange of the verge strip is inserted between the batten and the top of the wall (see B).
5. As the tiles are laid, ensure that the verge tiles are extended fully into the verge strip where they will be firmly held (see C).
6. T-strip connectors allow for a sprocket eaves and change in pitch up to 15° (see D).

For the Scot Strip follow the instructions above but fix directly onto boarding.



Uni-line Continuous Dry Verge

KLOBER



Weight (per carton)

T Strip	22kg
S Strip	11.6kg
Scot strip	7.2kg

Dimensions (approx size)

T Strip	130mm x 94mm
S Strip	90mm x 63mm
Scot Strip	80mm x 45mm

Packaging

T-, S- & Scot Strips

4 x 5m lengths per pack

T Strip Connectors

Packs of 2

Ridge End Caps

Packs of 2

Product codes

Black T Strip	KR980376
White T Strip	KR980377
Brown T Strip	KR980378
Black S Strip	KR980476
Black Scot Strip	KR980676

T Strip Connectors

Black	KR9805-0450
Brown	KR9805-0247
White	KR9805-0900

Ridge End Caps

Half round

Black	KR977276
Brown	KR977236
Slate grey	KR977230
Terracotta	KR977234
White	KR977277

Uni-Angle

Black	KR977376
Brown	KR977336
Slate grey	KR977330
Terracotta	KR977334
White	KR977377



Regulations

Complies fully with all relevant British Standards



Related products

The Klobber Uni-Line Continuous Dry Verge system may be used in conjunction with a wet or dry ridge system of your choice.

'T' Strip



'S' Strip



'Scot' Strip

