






KURTIS




PLEASE READ THROUGH THE INSTRUCTION BEFORE STARTING
PLEASE WORK IN A SAFE ENVIROMENT. USE SAFETY EQUIPMENT WHERE NECCESARY




Components shown full size






In all three support brackets drill two 6.5mm holes (one near the top, one near the bottom) in the back of the bracket 7mm from the edge and positioned vertically to suit the surface you are fixing to.




Starting with the middle bracket, position the bracket on the wall and mark the holes. Drill the holes with an 8mm masonry drill 60mm deep. Fit the wall plugs WP and bolt to the wall with coach screws CS using the tools

provided. Mark the positions of the other two brackets 640mm from the middle bracket keeping the tops of the brackets level. Mark, drill and fix as you did the middle bracket. If necessary use packing to bring the fronts of the brackets straight and level




Assemble the frame on a smooth clean surface.

Starting with the double gable push the eaves beams into place with the pre fitted cover plates on the inside of the frame. Fix the beams in through the top of the gable with long screws LS. Push the left and right gables on to the eaves beams and fix through the tops of the gables with long screws LS. Place the ridge beams over the tongue of the gables and fix with eight bolts A and nuts B with the nuts on the inside of the frame.




Fixing the roof tiles. Place panel 1 on the right hand gables with the connector strips over the centre of the double gable. Use the locators to find the position and fix down with four long screws LS. Place tile panel 2 over the first panel, line up the connector strip over the centre of the double gable and screw down with four long screws LS.

IMPORTANT if you are fitting your porch into a corner start by fixing the tiles nearest the corner first. The picture is correct for a right hand corner.




Push roof tile panel 3 into the connector strip on panel 1 use the location to find the position and fix down with four long screws LS. Place roof tile panel 4 over panel 3 and push into the connector strip on panel 2. Fix down with four long screws LS. Press cover buttons, texture side up into the holes to hide the screws. No flashing as been supplied with this kit. If you wish to fit one please purchase one which is suitable for your situation.


PARTS




Gable Left and Right 1 pair




Double gable x1




Bracket x3




Eaves beam with cover panel x2




Ridge beam x2



Ceiling panel x6



Roof tile connector x4 long x1 short



Roof tile x4